

HiQ® REDLINE® S 20. Single source manifold.



Application

HiQ REDLINE manifolds are suitable for all applications in analysis, as well as research and development, where high demands in gas purity, accuracy and reliability are required.

Description

S 20 is a wall-mounted manifold designed for one single gas source. The gas source might be one or more gas cylinders. S 20 is especially suitable for providing inert purge gas to manifolds with external purging. The manifold reduces a cylinder pressure of up to 200 bar to a distribution pressure. The house of the manifold is made of chrome-plated brass.

The standard configuration is equipped with a CE marked safety valve and a shut-off valve on the low-pressure side. In the basic configuration, the pressure protection consists of a relief valve and there is no low-pressure shut-off valve. A contact gauge, mounted on the high-pressure side, intended for connection to a low-level gas alarm system, is optional.

Quality assurance

Pressure regulators are designed and approved according to EN ISO 7291 (including the oxygen ignition test and the life cycle test). Valves are designed and approved according to relevant sections of EN ISO 10297 (including the oxygen pressure surge test). The equipment meets the electrostatic chargeability requirements of EN ISO 80079-36, IEC TS 60079-32-1 and the German TRGS 727. The manifolds can therefore be used in the EX zones 1 and 2 for gases with the explosion risk groups I, IIA, IIB or IIC. Each regulator and valve is seat leakage tested, atmosphere leakage tested and pressure tested with helium.



Versions HiQ REDLINE S 20

Product name	Material	Outlet pressure, bar(g)	Outlet pressure, psi(g)	Art. No.	
Basic version with relief	valve:				
S 20 B	Chrome-plated brass	1-14	15-203	342043	
Basic version with contact pressure gauge and relief valve: S 20 B C Chrome-plated brass 1–14 15–203 342045					
	afety valve and low press		13 203	3 120 13	
S 20 B SV SOV	Chrome-plated brass	1-14	15-203	342046	
Standard version with contact pressure gauge, safety valve and low pressure shut-off valve:					
S 20 B C SV SOV	Chrome-plated brass	1–14	15–203	342047	


Technical data

Pressures	bar(g)	psi(g)	
Maximum inlet pressure	230	3 336	
Outlet pressure range	1–14	15-203	
Relief/safety valve opening pressure	21.6/21	313/305	
Outlet gauge range	-1 to 25	-15 to 363	
Nominal flow	20 m ³ /h (nitrogen) acc. to ISO 7291		
Flow coefficients	Cv		
Shut-off valve	0.25		
Operating temperature	-20° C to +60° C	-4° F to +140° F	
Gas purity	≤6.0 (99.9999 %)		
Leakage rates			
to the atmosphere	≤1x10 ⁻⁹ mbar l/s (helium)		
through the seat	≤5x10 ⁻⁶ mbar l/s (helium)		
Particle filters			
Shut-off valve	100 μm (each inlet)	100 μm (each outlet)	
Pressure regulator	10 μm (inlet)	100 μm (each outlet)	
Materials			
Shut-off valve, house	Chrome-plated brass		
Shut-off valve, diaphragms	Hastelloy and Elgiloy		
Shut-off valve, seat	PCTFE		
Shut-off valve, poppet	Chrome-plated brass		
Pressure regulator, house	Chrome-plated brass		
Pressure regulator, diaphragm	Hastelloy		
Pressure regulator, seat	PCTFE		
Pressure regulator, poppet	Chrome-plated brass		
Relief/safety valve seat	FKM		
Connections			
Process gas inlet	NPT ¼" female		
Process gas outlet	NPT ¼" female		
Relief/safety valve outlet	12 mm tube fitting in stainless steel		
Weight	≤4.7 kg	≤10.4 lbs	




Installation

The manifold is easily installed due to separate mounting plates in polished stainless steel. A base plate is first mounted on the wall. The manifold, mounted on a front plate, is then simply hooked onto the base plate, and fixed with a screw. A safety wire of the high-pressure hose with a carabiner hook, can be attached to a hole in the base plate. Further, there is a grounding bolt in the base plate. Due to the cut-outs in the front plate, a faulty pressure gauge can be replaced without dismantling the manifold.



Flow curves

Outlet pressure 14 bar(g)




Accessories


High-pressures hose, coil and/or extension header rails for connection to the gas cylinder(s)/bundle(s) are ordered separately. Note that a tube fitting outlet connection is not included in the manifold.



Images, P&IDs and drawings Basic version with relief valve




Basic version with contact pressure gauge and relief valve






Images, P&IDs and drawings Standard version with safety valve and low pressure shut-off valve



Standard version with contact pressure gauge, safety valve and low pressure shut-off valve





Linde Gas AB Rättarvägen 3, SE-169 68 Solna, Sweden Tel +46 8 731 10 00, www.linde-gas.se